F6CTE DIRECT CONVERSION RECEIVER VERSION 1

SUPPLY DIAGRAM

HF – AF DIAGRAM

NOTES

* DECIMALS ARE SEPARATED BY A COMMA (AS IN 4,7 K)
* UH MEANS MICRO HENRY AND MH MEANS MILLI HENRY
* THE QUARTZ Q1 CAN HAVE DIFFERENT VALUES FROM 3,5 TO 10 MHZ